HD Integrated Camera AW-HE50HN/AW-HE50SN
Additional Instructions for the Operating Instructions <Basics>

The following additional details are being provided for inclusion in the Operating Instructions <Basics>.

Before use (<Basics>: page 7)

[Additional details]

■ Network security

- Refrain from connections that use public lines.

Operating precautions (<Basics>: page 13)

[Additional details]

Concerning the IP address setting

Do not set the IP address for one camera using the Easy IP Setup Software which is running concurrently in a multiple number of personal computers. Otherwise, you will be unable to complete the proper procedure and set the IP address correctly.

How to install and connect the unit (<Basics>: page 23)

● How to secure the DC plug



① **Loosely secure the cable clamp.**



Loosely secure the cable clamp in the area shown above.

② **Fasten the cable clamp.**



Take hold of the strap part, slide the cable clamp until it stops moving, and then secure it tightly.

Stand-alone installation (<Basics>: page 28)

● How to secure the DC plug



① **Loosely secure the cable clamp.**



Loosely secure the cable clamp in the area shown above.

② **Fasten the cable clamp.**



Take hold of the strap part, slide the cable clamp until it stops moving, and then secure it tightly.

3TU002261AAA